



| ORIGINAL      | SUPERIOR  |
|---------------|-----------|
| DVD           |           |
|               | POWER     |
| MENU / BROWSE | MENU      |
| 1/2/3/4/5     | 1/2/3/4/5 |
| 6/7/8/9/0     | 6/7/8/9/0 |
|               |           |
| UP            | UP        |
| DOWN          | DOWN      |
| LEFT          | LEFT      |
| RIGHT         | RIGHT     |
| OK            | OK        |
| i+            | INFO      |
| P < P         | EPG       |
| STOP / CANCEL | / SMART   |
| REW           | GREEN     |
| PLAY          | YELLOW    |
| FWD           | BLUE      |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |
|               |           |

| ORIGINAL      | SUPERIOR        |
|---------------|-----------------|
| VCR           |                 |
|               | SHIFT+POWER     |
| MENU / BROWSE | SHIFT+MENU      |
| 1/2/3/4/5     | SHIFT+1/2/3/4/5 |
| 6/7/8/9/0     | SHIFT+6/7/8/9/0 |
|               | SHIFT+          |
| UP            | SHIFT+UP        |
| DOWN          | SHIFT+DOWN      |
| LEFT          | SHIFT+LEFT      |
| RIGHT         | SHIFT+RIGHT     |
| OK            | SHIFT+OK        |
| i+            | SHIFT+INFO      |
| STOP / CANCEL | SHIFT+          |
| REC           | SHIFT+RED       |
| REW           | SHIFT+GREEN     |
| PLAY          | SHIFT+YELLOW    |
| FWD           | SHIFT+BLUE      |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |

