



ORIGINAL	SUPERIOR
	POWER
	MUTE
Q MENU	MENU
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MOVIES	 / AV
I – II	-/--
 / SMART	
	
 / SMART	
	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
 / WAKE UP	SLEEP
TV	TV/DTV
	INFO

[illegible]