



ORIGINAL	SUPERIOR
STANDBY	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SV / V+	 / AV
 / TIMER	-/--
P < P	
 / TELETEXT	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RED / CLEAR	RED
 / GREEN / SMART	GREEN
 / YELLOW / SMART	YELLOW
BLUE / AUDIO	BLUE
 / INDEX	SHIFT+ 
 / STILL	SHIFT+ 
STOP	SHIFT+ 

[illegible]