



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SV / V+	-/--
	
	
	
	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
INDEX	INFO
P > P	FAV
	
STOP	

[illegible]