



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
P < P	
 / TELETEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / TIMER	SLEEP
INDEX	INFO
 / STILL	 / SMART TUBE
RED	RED
GREEN /  / SMART	GREEN
YELLOW /  / SMART	YELLOW
BLUE	BLUE
STOP	SHIFT+ 

[illegible]