



| ORIGINAL           | SUPERIOR  |
|--------------------|-----------|
| STANDBY / ON       | POWER     |
| MENU               | MENU      |
| STATUS / EXIT      | EXIT      |
| 1/2/3/4/5          | 1/2/3/4/5 |
| 6/7/8/9/0          | 6/7/8/9/0 |
| SV / V+            | / AV      |
| TURBO TIMER        | -/--      |
| AUDIO              |           |
| SYSTEM             |           |
| P+                 | P+        |
| P-                 | P-        |
| CLEAR              | BACK      |
| SLOW               | SLEEP     |
| INDEX              | INFO      |
| EJECT              |           |
| ▶◀ / PAUSE / STILL |           |
| STOP               |           |
| REC / OTR          | RED       |
| REW                | GREEN     |
| PLAY               | YELLOW    |
| FWD                | BLUE      |
|                    |           |
|                    |           |
|                    |           |
|                    |           |
|                    |           |
|                    |           |
|                    |           |

| ORIGINAL      | SUPERIOR        |
|---------------|-----------------|
| TV            |                 |
| STANDBY / ON  | SHIFT+POWER     |
| MUTE          | SHIFT+MUTE      |
| MENU          | SHIFT+MENU      |
| STATUS / EXIT | SHIFT+EXIT      |
| 1/2/3/4/5     | SHIFT+1/2/3/4/5 |
| 6/7/8/9/0     | SHIFT+6/7/8/9/0 |
| VOL+          | SHIFT+VOL+      |
| VOL-          | SHIFT+VOL-      |
| P+            | SHIFT+ P+       |
| P-            | SHIFT+ P-       |
| UP            | SHIFT+UP        |
| DOWN          | SHIFT+DOWN      |
| LEFT          | SHIFT+LEFT      |
| RIGHT         | SHIFT+RIGHT     |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |
|               |                 |

