

ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
HOME/MENU	MENU
EXIT/TV	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	AV
ADJUST	-/--
SMART TV	
FORMAT	
OPTIONS	
TEXT	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK/P<P	BACK
SLEEP	SLEEP
TV/EXIT	TV/DTV
INFO	INFO

ORIGINAL	REPLACEMENT
GUIDE/LIST/FIND/TXT2	EPG
MEDIA/THEME TV	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SOUND	SHIFT+MUTE
3D	SHIFT+3
A/D	SHIFT+AV
AMBILIGHT	SHIFT+ 
PICTURE	SHIFT+ 
SETUP	SHIFT+ 
SUBTITLE	SHIFT+ 
CLOCK	SHIFT+SLEEP
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE
D.MENU	SHIFT+MENU

