



| ORIGINAL                   | SUPERIOR                                                                          |
|----------------------------|-----------------------------------------------------------------------------------|
| <b>SYANDBY / ON</b>        | <b>POWER</b>                                                                      |
| <b>SOUND</b>               | <b>MUTE</b>                                                                       |
| <b>SYSTEM – MENU</b>       | <b>MENU</b>                                                                       |
| <b>DIRECT PLAY – CD</b>    | <b>1</b>                                                                          |
| <b>DIRECT PLAY – CD-R</b>  | <b>2</b>                                                                          |
| <b>DIRECT PLAY – MD</b>    | <b>3</b>                                                                          |
| <b>DIRECT PLAY – TAPE</b>  | <b>4</b>                                                                          |
| <b>DIRECT PLAY – TUNER</b> | <b>5</b>                                                                          |
| <b>DIRECT PLAY – AUX</b>   | <b>6</b>                                                                          |
| <b>SET</b>                 | <b>-/--</b>                                                                       |
| <b>SYSTEM – DISP./CHA.</b> |  |
| <b>VOLUME+</b>             | <b>VOL+</b>                                                                       |
| <b>VOLUME-</b>             | <b>VOL-</b>                                                                       |
| <b>SKIP NEXT / +</b>       | <b>P+</b>                                                                         |
| <b>SKIP PREV. / -</b>      | <b>P-</b>                                                                         |
| <b>CANCEL</b>              | <b>BACK</b>                                                                       |
| <b>TIMER</b>               | <b>SLEEP</b>                                                                      |
| <b>STOP</b>                |  |
| <b>REW</b>                 | <b>GREEN</b>                                                                      |
| <b>FWD</b>                 | <b>BLUE</b>                                                                       |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |
|                            |                                                                                   |

| ORIGINAL | SUPERIOR |
|----------|----------|
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |

