

| ORIGINAL          | SUPERIOR                                                                               |
|-------------------|----------------------------------------------------------------------------------------|
| POWER             | POWER                                                                                  |
| MUTE              | MUTE                                                                                   |
| MENU              | MENU                                                                                   |
| EXIT              | EXIT                                                                                   |
| 1/2/3/4/5         | 1/2/3/4/5                                                                              |
| 6/7/8/9/0         | 6/7/8/9/0                                                                              |
| INPUT NEXT        |  / AV |
| AM/FM TOGGLE      | -/--                                                                                   |
| MOVIE             |       |
| ADVANCED          |       |
| MULTI CH. 5.1     |       |
| MULTI CH. BALANCE |       |
| VOL+              | VOL+                                                                                   |
| VOL -             | VOL -                                                                                  |
| PRESET NEXT       | P+                                                                                     |
| PRESET PREV.      | P -                                                                                    |
| UP                | UP                                                                                     |
| DOWN              | DOWN                                                                                   |
| LEFT              | LEFT                                                                                   |
| RIGHT             | RIGHT                                                                                  |
| OK                | OK                                                                                     |
| BACK              | BACK                                                                                   |
| SLEEP             | SLEEP                                                                                  |
| DIGITAL/ANALOG    | TV/DTV                                                                                 |
| DIALOG ENHANCE    | INFO                                                                                   |

| ORIGINAL          | SUPEROIR                                                                                      |
|-------------------|-----------------------------------------------------------------------------------------------|
| CH. SELECT        | EPG                                                                                           |
| SOUND MODE        | FAV                                                                                           |
| AUTO SURROUND     | RED                                                                                           |
| DIRECT TUNE       | GREEN                                                                                         |
| HIBIT             | YELLOW                                                                                        |
| LOUDNESS          | BLUE                                                                                          |
| SETUP             | SHIFT+MENU                                                                                    |
| EFFECT -          | SHIFT+1                                                                                       |
| EFFECT +          | SHIFT+2                                                                                       |
| LEVEL -           | SHIFT+3                                                                                       |
| LEVEL+            | SHIFT+4                                                                                       |
| MOV SUR -         | SHIFT+5                                                                                       |
| MOV SUR+          | SHIFT+6                                                                                       |
| VOL. CENTER DOWN  | SHIFT+7                                                                                       |
| VOL. CENTER UP    | SHIFT+8                                                                                       |
| VOL. REAR DOWN    | SHIFT+9                                                                                       |
| VOL. REAR UP      | SHIFT+0                                                                                       |
| INPUT ATTENUATION | SHIFT+  / AV |
| PRO LOGIC TOGGLE  | SHIFT+ -/--                                                                                   |
| TUNER DISPLAY     | SHIFT+       |
| MC ACC. SET       | SHIFT+      |
| MPX               | SHIFT+     |
| SYSTEM SETUP      | SHIFT+     |
| TUNE DOWN         | SHIFT+DOWN                                                                                    |
| TUNE UP           | SHIFT+UP                                                                                      |

[illegible]