



ORIGINAL	SUPERIOR
POWER RECEIVER	POWER
MUTE	MUTE
🏠 / HOME MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
BAND	📺 / SOURCE
CH. LEVEL	-/--
DISP.	📺
VIDEO PARAMETER	📺
CLASS	📺
T. EDIT	📺
MASTER VOLUME +/-	VOL +/-
CH +/-	P +/-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
A. ATT.	TV/DTV
STATUS	INFO
MPX	EPG
D. ACCESS	FAV
AUTO / ALC. / DIRECT	RED

ORIGINAL	SUPERIOR
STEREO	GREEN
STANDARD	YELLOW
ADV. SURR.	BLUE
AUDIO PARAMETER	SHIFT+MUTE
BD	SHIFT+1
CD	SHIFT+2
CD – R	SHIFT+3
DVD	SHIFT+4
DVR	SHIFT+5
HDMI	SHIFT+6
iPod USB	SHIFT+7
TUNER	SHIFT+8
TV	SHIFT+9
VIDEO	SHIFT+0
MCACC.	SHIFT+📺
PHASE CTRL.	SHIFT+📺
SB. CH.	SHIFT+📺
SIGNAL SEL.	SHIFT+📺
PRESET NEXT	SHIFT+UP
PRESET PREV	SHIFT+DOWN
INPUT SELECT ←	SHIFT+LEFT
INPUT SELECT →	SHIFT+RIGHT
2 nd ENTER	SHIFT+OK
DIMMER	SHIFT+INFO
PQLS.	SHIFT+EPG

