



ORIGINAL	SUPERIOR
STANDBY / ON	POWER
AUDIO	MUTE
🏠 / HOME MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNCTION	📺 / SOURCE
MENU / POPUP MENU	-/--
DISPLAY	📺
KEY LOCK	🔒
ANGLE	📺
SUBTITLE	📺
SKIP NEXT	P+
SKIP PREV	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
VIDEO OUTPUT RESET	TV/DTV
FRONT LIGHT	INFO
DISC NAV. / TOP MENU	EPG
CONTINUED	FAV
OPEN / CLOSE	📺 / NET TV

ORIGINAL	SUPERIOR
PAUSE	⏸
STOP	📺 / SMART
REV	GREEN
PLAY	YELLOW
FWD	BLUE
CLEAR	SHIFT+EXIT
SECONDARY VIDEO	SHIFT+📺
PAGE+	SHIFT+UP
PAGE -	SHIFT+DOWN
REPLAY	SHIFT+LEFT
SKIP SEARCH	SHIFT+RIGHT
REPEAT	SHIFT+BACK
REPEAT OFF	SHIFT+SLEEP
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE

