



ORIGINAL	SUPERIOR	ORIGINAL	SUPERIOR
STANDBY/ON	POWER		
TUNER PRESETS	MENU		
SOUND SCAPE ON/OFF	EXIT		
INPUT	 / SOURCE		
CLOCK	-/--		
SETUP			
VOLUME+	VOL+		
VOLUME -	VOL -		
TUNE+	P+		
TUNE -	P -		
SOUND SCAPE SELECT+	UP		
SOUND SCAPE SELECT -	DOWN		
MIX BALANCE -	LEFT		
MIX BALANCE+	RIGHT		
ENTER	OK		
SLEEP	SLEEP		
BASS/TREBLE	TV/DTV		
WAKE UP	INFO		
PRESET -	GREEN		
PLAY/PAUSE	YELLOW		
PRESET+	BLUE		

