



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	/ SOURCE
•	-/--
ASPECT	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
← BACK	BACK
	TV/DTV
i+	INFO
GUIDE	EPG
NETFLIX	/ NET TV

ORIGINAL	SUPERIOR
YOUTUBE	/ SMART TUBE
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
MTS	SHIFT+MUTE
P.MODE	SHIFT+
S.MODE	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
	SHIFT+BACK
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY/PAUSE	SHFIT+YELLOW
FWD	SHIFT+BLUE

