



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	 / SOURCE
P.MODE	
TELETEXT	
VOL +	VOL +
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
SLEEP	SLEEP
INFO	INFO
GUIDE	EPG
I/II	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW

[illegible]