



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
10+ / 	-/--
DISPLAY	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
SLEEP	SLEEP
TV/RADIO / TITLE	TV/DTV
FAV / PROGRAM	FAV
ASPECT / SIZE	 / NET TV
RED / GO TO	RED
GREEN / A – B	GREEN
YELLOW / ANGLE	YELLOW

[illegible]