



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
LIST	-/--
WIDE / 16:9	
TTX /	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
	SLEEP
INFO	INFO
SMART P.	/ NET TV
HOLD	/ SMART VIDEO
RED	RED

ORIGINAL	SUPERIOR
GREEN / SUBTITLE	GREEN
YELLOW / FAV	YELLOW
BLUE / EPG	BLUE
SMART S.	SHIFT+MUTE
F1	SHIFT+1
L / R	SHIFT+ -/--
REVEAL	SHIFT+
ZOOM	SHIFT+
LANGUAGE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
RADIO	SHIFT+ TV/DTV
INDEX	SHIFT+INFO
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

