



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
 / HOME	-/--
DISPLAY	
SIZE/ASPECT	
MIX	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
INDEX/REC LIST	INFO

ORIGINAL	SUPERIOR
CH. LIST	EPG
FAV	FAV
BROWSER	 / NET TV
 / MOUSE	
HOLD	 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
I/II / AUDIO	SHIFT+MUTE
REVEAL	SHIFT+ 
P.MODE	SHIFT+ 
S.MODE	SHIFT+ 
SUBTITLE	SHIFT+ 
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
T.SHIFT	SHIFT+SLEEP
STOP	SHIFT+ 
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

