



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
F1	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
LIST	-/--
REVEAL	
WIDE / 16:9	
SMRT P	
/ TTX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SMART S	SLEEP
L / R	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
	EPG
LANGUAGE	FAV
HOLD	/ SMART VIDEO
RED	RED
GREEN / SUBTITLE	GREEN
YELLOW / FAV	YELLOW
BLUE / EPG	BLUE
ZOOM	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
RADIO	SHIFT+TV/DTV
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

