



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
CH LIST	-/--
	
TXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
← BACK	BACK
INFO	INFO
NETFLIX	 / NET TV
GOOGLE	 / SMART TUBE
YOUTUBE	 / SMART VIDEO
RED	RED

[illegible]