



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
10+ / -/--	-/--
SHIFT	
P.MODE	
ASPECT	
TXT	
VOL+/-	VOL+/-
CH+/-	P+/-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RECALL	BACK
SLEEP	SLEEP
TV	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
AUTO	/ NET TV
HOLD	
FREEZE	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
S.MODE	SHIFT+MUTE
NICAM	SHIFT+1
SUBPAGE	SHIFT+2
AUDIO	SHIFT+3
GOTO	SHIFT+ -/--
REVEAL	SHIFT+
SIZE	SHIFT+
MIX	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT/PREV	SHIFT+ P+/-
REPEAT	SHIFT+BACK
INDEX	SHIFT+INFO
A – B	SHIFT+SLEEP
RADIO	SHIFT+TV/DTV
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

