



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
PROG. / LOCK	MENU
CLEAR / RESET	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ AV
CHANNEL 100	-/--
MONITOR	
X2	
SPEED	
COUNTER MEMORY	
VOLUME+	VOL+
VOLUME-	VOL-
CH+	P+
CH-	P-
SLOW+	UP
SLOW-	DOWN
VIDEO-	LEFT
VIDEO+	RIGHT
NORMAL	OK
REPEAT	BACK
SLEEP	SLEEP
VIDEO	TV/DTV
TIME SEARCH	INFO

ORIGINAL	SUPERIOR
CH. SEARCH	EPG
REC END / SEARCH	FAV
EJECT	
PAUSE / STILL	
STOP	
RECORD	RED
REW	GREEN
PLAY	YELLOW
F.FWD	BLUE
STANDBY	SHIFT+POWER
TRACKING+	SHIFT+ P+
TRACKING-	SHIFT+ P-
RECALL	SHIFT+BACK
TIMER	SHIFT+SLEEP
ADD / DELETE	SHIFT+TV/DTV
OTR	SHIFT+INFO
F. ADV / CS.	SHIFT+EPG
SLOW	SHIFT+FAV

