



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
LIST	-/--
PICTURE	
SOUND	
TV / TXT	
VOL+ / RIGHT	VOL+
VOL - / LEFT	VOL -
CH+ / UP	P+
CH - / DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
ASPECT	/ NET TV
HOLD	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
NICAM / A2	SHIFT+MUTE
CANCEL	SHIFT+EXIT
CHANNEL LIST	SHIFT+ -/--
REVEAL	SHIFT+
SIZE	SHIFT+
SUBTITLE	SHIFT+
SUBPAGE	SHIFT+DOWN
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
REPEAT	SHIFT+BACK
INDEX	SHIFT+INFO
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

