



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
M / MENU	MENU
X / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 ?	-/--
	
TEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
AD	TV/DTV
INFO	INFO
	EPG
FAV	FAV
RED	RED
GREEN	GREEN

[illegible]