



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
SYS-MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	/ SOURCE
-/--	-/--
DISPLAY	
PICTURE	
INDEX	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TIMER	SLEEP
TV / TXT	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
HOLD / PROG -	/ SMART
RED / TV/RADIO	RED
GREEN / AUDIO	GREEN
YELLOW / FREEZE	YELLOW
BLUE / SUBTITLE	BLUE
SOUND	SHIFT+MUTE
DVB-MENU	SHIFT+MENU
NICAM / A2	SHIFT+1
CANCEL	SHIFT+EXIT
REVEAL	SHIFT+
SIZE / PROG+	SHIFT+
TV FORMAT	SHIFT+
LANGUAGE	SHIFT+
SUBPAGE	SHIFT+DOWN

