



| ORIGINAL   | SUPERIOR  |
|------------|-----------|
| POWER      | POWER     |
| MUTE       | MUTE      |
| SYS – MENU | MENU      |
| EXIT       | EXIT      |
| 1/2/3/4/5  | 1/2/3/4/5 |
| 6/7/8/9/0  | 6/7/8/9/0 |
| TV / AV    | / SOURCE  |
| -/--       | -/--      |
| DISPLAY    |           |
| PICTURE    |           |
| INDEX      |           |
| TEXT       |           |
| VOL+       | VOL+      |
| VOL -      | VOL -     |
| CH+        | P+        |
| CH -       | P -       |
| UP         | UP        |
| DOWN       | DOWN      |
| LEFT       | LEFT      |
| RIGHT      | RIGHT     |
| OK         | OK        |
| RETURN     | BACK      |
| TIMER      | SLEEP     |
| TV / TXT   | TV/DTV    |
| INFO       | INFO      |

| ORIGINAL        | SUPERIOR   |
|-----------------|------------|
| EPG             | EPG        |
| FAV             | FAV        |
| HOLD / PROG -   | / SMART    |
| RED / TV/RADIO  | RED        |
| GREEN / AUDIO   | GREEN      |
| YELLOW / FREEZE | YELLOW     |
| BLUE / SUBTITLE | BLUE       |
| SOUND           | SHIFT+MUTE |
| DVB-MENU        | SHIFT+MENU |
| NICAM / A2      | SHIFT+1    |
| CANCEL          | SHIFT+EXIT |
| REVEAL          | SHIFT+     |
| SIZE / PROG+    | SHIFT+     |
| TV FORMAT       | SHIFT+     |
| LANGUAGE        | SHIFT+     |
| SUBPAGE         | SHIFT+DOWN |
|                 |            |
|                 |            |
|                 |            |
|                 |            |
|                 |            |
|                 |            |
|                 |            |
|                 |            |
|                 |            |

