



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	 / SOURCE
•	-/--
SIZE	
TV / TXT	
VOL+ / RIGHT	VOL+
VOL - / LEFT	VOL -
CH+ / UP	P+
CH - / DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
DTV	TV/DTV
INFO	INFO
EPG	EPG
FAV LIST	FAV

ORIGINAL	SUPERIOR
QUICK START	 / NET TV
FREEZE	
HOLD	 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
I / II	SHIFT+MUTE
CANCEL	SHIFT+EXIT
PICTURE	SHIFT+1
SOUND	SHIFT+2
REVEAL	SHIFT+ 
ZOOM	SHIFT+ 
SUBTITLE	SHIFT+ 
SUBPAGE	SHIFT+DOWN
FAV ►►I	SHIFT+RIGHT
TIME	SHIFT+SLEEP
INDEX	SHIFT+INFO
FAV ADD	SHIFT+FAV

