



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
[Menu Icon] / MENU	MENU
[Exit Icon] / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
[Function Icon] / FUNCTION	[Source Icon] / SOURCE
TITLE MENU / POPUP	-/--
DSP	[DSP Icon]
SFE MODE	[SFE Mode Icon]
2D - 3D	[2D-3D Icon]
FULL SCREEN	[Full Screen Icon]
VOL+	VOL+
VOL -	VOL -
TUNING / CH+	P+
TUNING / CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
[Enter Icon]	OK
[Return Icon] / RETURN	BACK
SLEEP	SLEEP
V - TUNER	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
PL II	EPG
[Tools Icon] / TOOLS	FAV
SMART HUB	[Smart Hub Icon] / SMART
RED / A	RED
GREEN / B / IPOD SYNC	GREEN
YELLOW / C / TUN MEM	YELLOW
BLUE / D / MO/ST	BLUE
VERTICAL SURROUND	SHIFT+MUTE
SEARCH	SHIFT+EXIT
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
REPEAT	SHIFT+BACK
EJECT	SHIFT+ [Up Arrow]
PAUSE	SHIFT+ [Pause]
STOP	SHIFT+ [Stop]
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

