



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
LOGO	/ SOURCE
MO./ST. / SLOW	-/--
SLIDE MODE	
DIGEST	
EZ. VIEW	
TEST TONE	
VOLUME+	VOL+
VOLUME -	VOL -
TUNING UP	P+
TUNING DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER /	OK
RETURN /	BACK
SLEEP	SLEEP
DOLBY PL. II MODE	TV/DTV
INFO	INFO
DSP. / EQ.	EPG

ORIGINAL	SUPERIOR
DOLBY PL. II EFF.	FAV
OPEN / CLOSE	/ NET TV
REMAIN	
STOP	/ SMART
SKIP PREV	GREEN
PLAY / PAUSE	YELLOW
SKIP NEXT	BLUE
SOUND EDIT	SHIFT+MUTE
AUX	SHIFT+1
DVD	SHIFT+2
TUNER / BAND	SHIFT+3
ZOOM	SHIFT+
SUBTITLE	SHIFT+
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
TUNER MEM. / P SCAN	SHIFT+TV/DTV
DIMMER	SHIFT+INFO

