



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNCTION / TV SOURCE	/ SOURCE
DSP	-/--
TITLE MENU / POPUP	
SW LEVEL	
TOOLS	
FULL SCREEN	
VOL+	VOL+
VOL -	VOL -
TUNING / CH+	P+
TUNING / CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP	SLEEP
V – SOUND	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
V – TUNER	EPG
SMART HUB	/ SMART
RED	RED
GREEN	GREEN
YELLOW / TUN. MEMORY	YELLOW
BLUE / MO/ST	BLUE
DISC MENU	SHIFT+MENU
SEARCH	SHIFT+EXIT
RDS DISPLAY	SHIFT+1
TA	SHIFT+3
PTY -	SHIFT+4
PTY SEARCH	SHIFT+5
PTY+	SHIFT+6
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
REPEAT	SHIFT+BACK
EJECT	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

