



ORIGINAL	SUPERIOR
	POWER
	MUTE
/ MENU	MENU
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TEST TONE	/ SOURCE
REMAIN	-/--
LOGO	
ZOOM	
DSP/EQ	
SUBTITLE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RETURN	BACK
SLEEP	SLEEP
MO /ST SLOW	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
PLII MODE	EPG
PLII EFFECT	FAV
OPEN/CLOSE	/ NET TV
STOP	/ SMART VIDEO
PLAY/PAUSE	YELLOW
AUDIO	SHIFT+MUTE
DIGEST	SHIFT+MENU
TUNER	SHIFT+1
AUX	SHIFT+2
DVD	SHIFT+3
TUN/CH+	SHIFT+ P+
TUN/CH -	SHIFT+ P -
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
NT/PAL TUNER MEMORY	SHIFT+TV/DTV
DIMMER	SHIFT+INFO
SOUND EDIT	SHIFT+EPG
P. SCAN TUNER MEMORY	SHIFT+FAV

