



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AUX	/ SOURCE
DVD	-/--
DISPLAY	
GOTO	
SETUP	
SUBTITLE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
BAND / TUNER	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
PROGRAM	EPG
REMAIN	FAV
OPEN/CLOSE	/ NET TV
STOP	/ SMART
REW / TUNING -	GREEN
PLAY/PAUSE	YELLOW
FWD / TUNING+	BLUE
MO/ST AUDIO	SHIFT+MUTE
SOUND EDIT	SHIFT+MENU
SLOW	SHIFT+EXIT
SPK MODE	SHIFT+
ZOOM	SHIFT+
ANGLE	SHIFT+
D.R.C.	SHIFT+
DSP/DLII MODE	SHIFT+LEFT
DSP/DLII EFFECT	SHIFT+RIGHT
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
TEST TONE	SHIFT+TV/DTV
PRO LOGIC II	SHIFT+EPG
A <--> B REPEAT	SHIFT+FAV

