



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
ON	POWER
	MUTE
MAIN MENU	MENU
STANDBY	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/10-0	6/7/8/9/0
SNOOZE	-/--
DIMMER	
AUTO SCAN	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT/TUNING -	LEFT
RIGHT/TUNING+	RIGHT
SELECT	OK
BACK	BACK
SLEEP	SLEEP
	TV/DTV
INFO	INFO
	EPG
★	FAV
< PRESET	GREEN

[illegible]