



FUNCTION	 / SOURCE
BASS	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
TUNING/FILE -	LEFT
TUNING/FILE+	RIGHT
REPEAT/FM MODE	BACK
SLEEP	SLEEP
RANDOM	TV/DTV
FOLDER/PRESET	INFO
MEMORY	EPG
SOUND	FAV
OPEN/CLOSE	 / NET TV
STOP	 / SMART
USB REC/PAUSE	RED
CD PLAY/PAUSE	YELLOW
USB/PLAY/PAUSE	BLU
SD REC/PAUSE	SHIFT+RED
SD PLAY/PAUSE	SHIFT+YELLOW

[illegible]