



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
PLAY LIST	-/--
/ PIP	
PIP S. LIST	
/ PIP SWAP	
/ TELETEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RECALL	BACK
RESOLUTION	SLEEP
TV / RAD.	TV/DTV
INFO	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
RED /	RED
GREEN /	GREEN
YELLOW /	YELLOW
BLUE /	BLUE
/ SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV.	SHIFT+ P-
PAGE UP	SHIFT+UP
PAGE DOWN	SHIFT+DOWN
	SHIFT+OK
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / TIME	SHIFT+YELLOW
FWD	SHIFT+BLUE

