



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
CH. LST	-/--
PICTURE	
SIZE	
MIX	
TEXT	
VOL+	VOL+
VOL -	VOL -
PROG/PAGE+	P+
PROG/PAGE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
FAV	FAV
ASPECT	/ NET TV
FREEZE	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO LANG / I/II	SHIFT+MUTE
CANCEL	SHIFT+EXIT
REVEAL	SHIFT+
SOUND	SHIFT+
SUBPAGE	SHIFT+
SUBTITLE	SHIFT+
TIME	SHIFT+SLEEP
INDEX	SHIFT+INFO

