



ORIGINAL	SUPERIOR
ON / STAND BY	POWER
MUTE	MUTE
MENU / PBC	MENU
SLOW	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNCTION	 / SOURCE
+10	- / --
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
NTSC / PAL	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
PROGRAM	EPG
LANGUAGE	FAV
OPEN / CLOSE	
STOP	
REW	GREEN
PLAY / PAUSE	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
MODE	SHIFT+  /
LISTENING	SHIFT+ - / --
DIRECT	SHIFT+ 
ANGLE	SHIFT+ 
A ñ B	SHIFT+ 
EQ	SHIFT+ 
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
ST / MO	SHIFT+TV/DTV
DIMMER	SHIFT+INFO
MEMORY	SHIFT+EPG
I/P SCAN	SHIFT+FAV

