



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
-/--	-/--
REVEAL	
SIZE	
TXT / PAGE -	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / REPEAT	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
ASPECT	 / NET TV

ORIGINAL	SUPERIOR
HOLD / FAV+	 / SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
I/II / AUDIO	SHIFT+MUTE
REC. MENU	SHIFT+MENU
PIC. MODE	SHIFT+1
S. MODE	SHIFT+2
CH. EDIT	SHIFT+3
CH. GROUP	SHIFT+4
SUBTITLE	SHIFT+ 
SUBPAGE / FAV -	SHIFT+DOWN
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
INDEX / PAGE+	SHIFT+INFO
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

