



ORIGINAL	SUPERIOR
STANDBY	POWER
	MUTE
MENU	MENU
CLR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIDEO OUT	/ AV
10+	-/--
DISPLAY	
ZOOM	
SETUP	
/ SUBTITLE	
VOL+	VOL+
VOL-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
SLEEP	SLEEP
PAL / NTSC	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
/ ANGLE	EPG
PROGRAM	FAV
OPEN / CLOSE	
PAUSE / STEP	
STOP	
REW	GREEN
PLAY	YELLOW
FWD	BLUE
/ AUDIO	SHIFT+MUTE
/ SEARCH	SHIFT+EXIT
3D	SHIFT+3
CARD	SHIFT+ / AV
SHUFFLE	SHIFT+ -/--
SLOW	SHIFT+BACK
A-B	SHIFT+SLEEP
/ DIMMER	SHIFT+INFO
DIGEST	SHIFT+EPG
MARK	SHIFT+FAV

