



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV / S	/ SOURCE
-/--	-/--
DISPLAY	
VIDEO MODE	
AUDIO MODE	
TELETEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
MENU	OK
	BACK
OFF TIMER	SLEEP
INDEX	INFO
SURROUND	FAV
WIDE	/ NET TV

ORIGINAL	SUPERIOR
HOLD	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
VIDEO MUTE	SHIFT+MUTE
PIP / POP	SHIFT+1
SWAP	SHIFT+2
POSITION	SHIFT+3
SCART	SHIFT+4
COMPONENT	SHIFT+5
PC / DVI	SHIFT+6
SUB SOURCE	SHIFT+
PREVIEW / FULL	SHIFT+
ZOOM	SHIFT+
ROTATE	SHIFT+
SUB PAGE	SHIFT+
PAGE DOWN	SHIFT+DOWN
PAGE UP	SHIFT+UP
CARD PLAY	SHIFT+OK
AI AUDIO	SHIFT+EPG
SOUND	SHIFT+FAV
AUTO PLAY	SHIFT+YELLOW

