



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	
UP / CHANNEL+	UP
DOWN / CHANNEL -	DOWN
LEFT / VOL -	LEFT
RIGHT / VOL+	RIGHT
OK	OK
ALT	BACK
TV	TV/DTV
i	INFO
EPG	EPG
BROWSE	FAV
FREEZE	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SUB	SHIFT+ 
PAGE+	SHIFT+UP

[illegible]