



ORIGINAL	SUPERIOR
	POWER
	MUTE
/ MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
PLAY LIST	-/--
RESOLUTION	
V – FORMAT	
/ TELETEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RECALL	BACK
SLEEP	SLEEP
TV / RAD	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED /	RED
GREEN /	GREEN
YELLOW / ?	YELLOW
BLUE /	BLUE
/ PIP	SHIFT+
/ PIP SWAP	SHIFT+
PIP S. LIST	SHIFT+
/ SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV.	SHIFT+ P-
PAGE UP	SHIFT+UP
PAGE DOWN	SHIFT+DOWN
TIME	SHIFT+SLEEP
EJECT	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
WD	SHIFT+BLUE

