



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT / PVR LIST	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
CHN. LIST / QUICK	-/--
P. M.	
ZOOM	
MIX	
TEXT	
VOL+	VOL+
VOL -	VOL -
PR.+	P+
PR. -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP	SLEEP
SUB PAGE	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
FREEZE / HOLD	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
I/II / NICAM	SHIFT+MUTE
CANCEL	SHIFT+EXIT
3D	SHIFT+3
REVEAL	SHIFT+
SIZE	SHIFT+
S. M.	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
INDEX	SHIFT+INFO
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

