



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
-/--	-/--
/ HOME	
SIZE	
MIX	
/ TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
	BACK
SLEEP	SLEEP
MOUSE	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
INDEX	EPG
FAV	FAV
AUTO / NICAM/A2	/ NET TV
HOLD	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
REVEAL	SHIFT+
P.M	SHIFT+
S.M	SHIFT+
/ SUBPAGE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY/PAUSE	SHFIT+YELLOW
FWD	SHIFT+BLUE

