



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTING	MUTE
DVD MENU / FM MODE	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD	 / SOURCE
2 CH.	-/--
DISPLAY	
MOVIE	
MUSIC	
VOL +	VOL +
VOL -	VOL -
PRES/SKIP NEXT/CH+	P +
PRES/SKIP PREV/CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
SLEEP / TV INPUT	SLEEP
INPUT TV	TV/DTV
A.F.D.	EPG
AUTO CAL.	 / NET TV
REW/TUN. DOWN	GREEN
FWD/TUN. UP	BLUE

[illegible]