



ORIGINAL	SUPERIOR
	POWER
	MUTE
HOME	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/	/ AV
TITLE LIST	-/--
NETFLIX	
OPTIONS	
VOL+	VOL+
VOL-	VOL-
PROG+ /	P+
PROG- /	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
RETURN	BACK
SLEEP	SLEEP
DIGITAL / ANALOG	TV/DTV
i+ /	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SYNC. MENU	SHIFT+MENU
	SHIFT+
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
	SHIFT+BACK
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

