



ORIGINAL	SUPERIOR
	POWER
	MUTE
SYSTEM MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	AV
	-/--
SCENE SEARCH	
SOUND MODE	
HOME	
VOL+	VOL+
VOL-	VOL-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP	SLEEP
TV	TV/DTV
DISPLAY / i+ / ?	INFO
➡ / ADVANCE	EPG
TOP MENU	FAV

ORIGINAL	SUPERIOR
NIGHT	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
/ DIGITAL	SHIFT+MUTE
POP UP MENU	SHIFT+MENU
ONE TOUCH PLAY	SHIFT+
DYNAMIC BASS	SHIFT+
/ D. TUNING / ANALOG	SHIFT+
SKIP NEXT / PRESET+	SHIFT+ P+
SKIP PREV. / PRESET-	SHIFT+ P-
⏮ / REPLAY	SHIFT+BACK
TIME / -/--	SHIFT+SLEEP
OPTION / TOOLS	SHIFT+TV
PAUSE	SHIFT+
STOP	SHIFT+
REW / TUNING-	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD / TUNING+	SHIFT+BLUE

