



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
TOOL MENU	MENU
CLEAR	EXIT
AUDIO IN	1
CD	2
IPOD	3
TAPE	4
TUNER	5
USB	6
INPUT NEXT	 / SOURCE
TUNING/PLAY MODE	-/--
DISPLAY	
EQ.	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT / TUNE+	P+
SKIP PREV / TUNE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP	SLEEP
TUNER MEMORY	EPG

[illegible]