



ORIGINAL	SUPERIOR
	POWER
	MUTE
HOME	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	/ SOURCE
TITLE LIST	-/--
SOCIAL VIEW	
DIGITAL / ANALOG	
OPTIONS	
VOL+	VOL+
VOL -	VOL -
/ PROG.+	P+
/ PROG. -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
RETURN / BACK	BACK
DISCOVER	SLEEP
TV / RADIO	TV/DTV
/ i+	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
TV PAUSE	/ SMART TUBE
APPS / SEN	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SYNC. MENU	SHIFT+MENU
RELATED SEARCH	SHIFT+EXIT
3D	SHIFT+3
	SHIFT+
i - MANUAL / ?	SHIFT+INFO
FOOTBALL	SHIFT+FAV
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

