



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV/AV	/ SOURCE
GO TO	-/--
DEV	
FIND	
MP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TV/R	TV/DTV
i+	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
ASPECT	/ NET TV
RED	RED
GREEN / INFO	GREEN
YELLOW / ZOOM	YELLOW
BLUE / OPTIONS	BLUE
AUDIO	SHIFT+MUTE
SAT	SHIFT+7
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

