



ORIGINAL	REPLACEMENT	ORIGINAL	REPLACEMENT
POWER	POWER	STOP	
MUTE	MUTE	REW	GREEN
	MENU	PLAY / PAUSE	YELLOW
	EXIT	FWD	BLUE
	1		SHIFT+MUTE
	0		SHIFT+
SOURCE	AV		
	-/--		
LED			
TOOLS			
VOL+	VOL+		
VOL-	VOL-		
SKIP NEXT	P+		
SKIP PREV.	P-		
UP	UP		
DOWN	DOWN		
LEFT	LEFT		
RIGHT	RIGHT		
ENTER	OK		
BACK	BACK		
	INFO		
	EPG		

